REVISION

2.86F

KoamTac

A New Wave in Auto ID

User Manual KDC300

December, 2009

TABLE OF CONTENTS

LISTING OF FIGURES **5**

LISTING OF TABLES **6**

1. INTRODUCTION **8**

1.1 KDC Package 9
1.2 KDC Characteristics 10

2. INSTALLATION **12**

2.1 KoamTac Installation Wizard 12
Windows XP 12
Vista and Windows 7 17
Windows Mobile 5.0+ 20
2.2 Manual Installation 22
Windows XP, Vista, and 7 22
Windows Mobile 5.0+ 22

3. OPERATING THE KDC **23**

3.1 Getting Started 23
Attach Neck Strap to KDC 23
Charge KDC Battery 23
Configure KDC 24
3.2 Basics 25
Reading Barcodes 25
Synchronizing Barcode Data to PC 25
3.3 KDC Menus 26
KDC Mode Menu 28
View Data Menu 28
Set Barcodes Menu 28
Code Options Menu 28
Scan Options Menu 28
Data Process Menu 29
Data Editor Menu 29
Bluetooth Menu - KDC200 / KDC200P / KDC300 30
System Menu 31
3.4 LED Status 32
3.5 Empty Battery 32
3.6 Buffer Full 32
3.7 Reset Feature 33
3.8 Replace Battery 34

4. BLUETOOTH - KDC200 / KDC200P / KDC300 ..... **35**

4.1 Power 35
4.2 Pairing 35
4.3 Auto Connect 36
4.4 Auto Power On 36

4.5 Auto Power Off 36
4.6 Beep Warning 36
4.7 PWR OFF Time 37
4.8 PowerOFF Msg 37
4.9 MAC Address 37
4.10 BT FW Version 37
4.11 Connect To 37
4.12 Wakeup Nulls 37

5. SYNCHRONIZATION 38

5.1 KTSync Menu 38
5.2 File Menu 41
Connect to KDC 41
Synchronize 41
Bluetooth 42
5.3 Synchronization Settings 43
Destination of Data 43
Synchronization Methods 44
Current KDC Wedge Method 45
Synchronization Options 46
Application Options 46
5.4 Barcode & KDC Settings 47
Select Symbologies and Symbology Options 48
Data Editing Option 48
5.5 Others Settings 49
5.6 Mobile pKTSync 50

6. APPLICATION GENERATION 51

6.1 Application Generation 52
Generate Application 52
Data Filter Settings 53
Application Download and Execution 55
6.2 Predefined Applications 56
Master/Slave 56
Pick/Bin 58
DB Lookup Application 60

7. TROUBLESHOOTING 62

8. WARRANTY 63

9. CONTACT INFORMATION 64

APPENDIX A - BARCODE & SCAN OPTIONS 65

Equation to Determining Potential Number of Stored Barcodes 66
Data Buffer Full 66
B.1 Symbology 67
B.2 Host Interface 68
B.3 Battery 68
B.4 Memory 68
B.5 Programming 69

APPENDIX C - SPECIAL BARCODES 70
C.1 Set Symbologies 70
C.2 Barcode Options 70
C.3 Delete Last Scanned Barcode 70
C.4 Scan Options 71
C.5 Scan Timeout 71
C.6 Minimum Barcode Length 73
C.7 Data Process - Wedge/Store 77
C.8 Data Process - Data Format - Handshake 78
C.9 Data Process - Termination Character 79
C.10 Bluetooth 80
C.11 Bluetooth PWR Off Time 82
C.12 System 85
C.13 Sleep Timeout 87
C.14 Function 89
C.15 Number 91
C.16 Lower Case Alphabet 92
C.17 Upper Case Alphabet 95
C.18 Control Character 98
C.19 Symbol Character 99

INDEX 103

LISTING OF FIGURES

Figure 1 – KDC Package 9
Figure 2 - Characteristics of KDC100 10
Figure 3 - Characteristics of KDC200 - KDC200P - KDC300 11
Figure 4 - Location of Scroll Buttons 24
Figure 5 - KDC Display 25
Figure 6 - Reset Function for KDC200 - KDC200P - KDC300 33
Figure 7 - Reset Function of KDC100 33
Figure 8 - Replacing KDC Battery 34
Figure 9 - KTSync® Synchronizer Menu 38
Figure 10 – File Menu 39
Figure 11 – Setting Menu 39
Figure 12 – Application Menu 40
Figure 13 – About Menu 40
Figure 14 - COM Port Selection for KDC 41
Figure 15 - Bluetooth Device Registry 42
Figure 16 - KTSync® Synchronization Settings 43
Figure 17 - Barcode & KDC Settings, Symbologies, Data Editing and Scan Options 47
Figure 18 - KTSync® Confirmation Settings 49
Figure 19 – Mobile pKTSync 50
Figure 20 – Application Menu 51
Figure 21 – Application Warning Window 51
Figure 22 – Application Generation Menu 52
Figure 23 – Data Filter Settings 53
Figure 24 – Master/Slave Application Settings 56
Figure 25 – Master/Slave Application Flow Chart 57
Figure 26 – Pick/BIN Application Menu 58
Figure 27 – Pick/BIN Application Flow Chart 59
Figure 28 – DB Lookup Application Menu 61

LISTING OF TABLES

Table 1 - Features of KDC 8
Table 2 – Approximate Time to Charge KDC Battery 23
Table 3 – KDC Menu Options 27
Table 4 – Factory Default Settings for KDC300 31
Table 5 - Explanation of LEDs 32
Table 6 - Troubleshooting Techniques 62
Table 7 - Symbologies Supported by KDC 65
Table 8 – Listing of Symbologies Supported by KDC 67

COPYRIGHT, LICENSE, and WARNING PAGE

Copyright© 2009 by KoamTac, Inc. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission in writing from KoamTac, Inc. The material in this manual is subject to change without notices. KoamTac reserves the right to make changes to any product to improve reliability, function, or design. KoamTac doesn't assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein. Follow all warnings and instructions marked on manual and units. Use only the power source specified in this manual or marked on the units.

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO ANY TYPE OF MOISTURE. DO NOT LOOK DIRECTLY INTO LASER OR POINT THE LASER INTO ANOTHER PERSON'S EYES. EXPOSURE TO THE BEAM MAY CAUSE EYE DAMAGE.

CAUTION:

Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:
This equipment has been tested and found to comply with the limit of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation; if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user, is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient / Relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit difference from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

WARNING:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

1. INTRODUCTION

Congratulations on purchasing KoamTac's revolutionary barcode scanner and data collector. Lightweight and compact, with a user-friendly design and superior functionality, KoamTac's KDC works in a variety of portable applications. Use it independently or as an accessory to your PC, PDA, or smartphone. To find out more about KoamTac, Inc. and our family of products, visit us at www.koamtac.com.

FEATURES	KDC100	KDC200	KDC200P	KDC300
USB CONNECTIONS	2	1	1	**1**
RECHARGEABLE BATTERY	YES	YES	YES	**YES**
SCAN ENGINE	Laser	Laser	Laser	**Imager**
AUTOMATIC DATA UPLOAD	YES	YES	YES	**YES**
STORES 10,000+ BARCODES	YES	YES	YES	**YES**
KTSYNC® SOFTWARE	YES	YES	YES	**YES**
SDK FOR DEVELOPERS	YES	YES	YES	**YES**
SUPPORTS MICROSOFT© WINDOWS XP, VISTA, 7 & MOBILE 5.0+	YES	YES	YES	**YES**
***BLUETOOTH* ENABLED**	NO	YES	YES	**YES**

Table 1 - Features of KDC

1.1 KDC Package

The standard KDC package contains:

1. One KDC Barcode Data Collector
2. One USB Cable
3. One Neck Strap
4. KoamTac Installation CD with
   - KTSync© for Microsoft Windows XP, Vista, 7 and Mobile 5.0+
   - KDC Device Driver
   - User Manual
5. One Protective Rubber Case (Optional)

NOTE: Depending on your region or distributor, package contents may vary.

Figure 1 – KDC Package

1.2 KDC Characteristics

Before you use your KDC, please become familiar with its physical characteristics. Refer to Figure 2 and Figure 3 below which indicate placement of scan and scroll buttons, OLED display, LEDs, and ports on your KDC. All KDC models are similar except for the KDC100 which includes an additional USB connector.

KDC100 Barcode Reader and Data Collector



Figure 2 - Characteristics of KDC100

KDC200 - KDC200P - KDC300
Barcode Reader and Data Collector

(KDC200, KDC200P)



(KDC300)

Figure 3 - Characteristics of KDC200 - KDC200P - KDC300

2. INSTALLATION

2.1 KoamTac Installation Wizard

Windows XP

WARNING: ***DO NOT CONNECT KDC TO USB PORT PRIOR TO INSTALLATION***

1. Insert KoamTac Installation CD into your computer's CD drive.
2. Click **Start** icon then **My Computer** icon. A listing of devices on your computer will display including the disk drive containing the KoamTac Installation CD.
3. Click on the KoamTac Installation CD icon then click on the Setup directory. Click on the PC_Setup.exe file which executes the KTSync Setup Wizard.

NOTES

- If KTSync Setup Wizard locates an older version of KTSync on your computer, you will be prompted to remove the older program before installing the new version. Select Remove KTSync then click Finish. When removal is complete, click Close. Go to Step 2 to run KTSync Setup Wizard.
- If you have any problems, please refer to the Manual Installation section.

KTSync Setup Wizard

Below are the screen images you will see during the installation of KTSync.

- Click **Next** icon in KTSync Setup Wizard window


KTSync
Welcome to the KTSync Setup Wizard
The installer will guide you through the steps required to install KTSync on your computer.
Click "Next" to continue.
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.
Cancel
Previous
Next

- Click **Next** icon in KTSync Confirm Installation window



- Within a few minutes, installation of KTSync is complete. Click **Close** icon and wait for the Device Driver Installation Wizard to load.



Device Driver Installation Wizard

Below are the screen images you will see during the installation of the KDC Device Driver.

- Click **Next** icon in Device Driver Installation Wizard window


Device Driver Installation Wizard
Welcome to the Device Driver Installation Wizard!
This wizard helps you install the software drivers that some computers devices need in order to work.
To continue, click Next.
< Back
Next >
Cancel

- Click **Continue Anyway** icon in Software Installation Logo testing window


Software Installation
The software you are installing has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the software vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

- Click **Finish** icon in Device Driver Installation Wizard window


Device Driver Installation Wizard
Completing the Device Driver Installation Wizard
The drivers were successfully installed on this computer.
You can now connect your device to this computer. If your device came with instructions, please read them first.
Driver Name
Status
KoamTac Data Collector...
Ready to use
< Back
Finish
Cancel

Connect KDC to Computer

Using the USB cable included with the KDC, follow the directions below.

- Connect the cable's ultra mini USB connector to the KDC.
- Connect the cable's Type A USB connector to your PC.
- Wait until your computer beeps and/or displays the message Found *New Hardware.*

Found New Hardware Wizard

- Select "No, not this time" option in Found New Hardware Wizard and click Next if your PC pops up the following Found New Hardware Wizard.

Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission).
Read our privacy policy
Can Windows connect to Windows Update to search for software?
Yes, this time only
Yes, now and every time I connect a device
No, not this time
Click Next to continue.
< Back
Next >
Cancel

- Select "Install the software automatically (Recommended)" option in Found New Hardware Wizard and click Next if your PC pops up the following Found New Hardware Wizard.


Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
This wizard helps you install software for:
Koamtac Data Collector
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

- Click **Continue Anyway** icon in Software Installation Logo testing window


Hardware Installation
The software you are installing for this hardware:
Koamtac Data Collector
has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

- Click **Finish** icon in Found New Hardware Wizard window



Verify COM Port Address

- User can verify installed COM Port in Device Manager



Vista and Windows 7

WARNING: ***DO NOT CONNECT KDC TO USB PORT PRIOR TO INSTALLATION***

1. Insert KoamTac Installation CD into your computer's CD drive.
2. Click **Start** icon then **My Computer** icon. A listing of devices on your computer will display including the disk drive containing the KoamTac Installation CD.
3. Click on the KoamTac Installation CD icon then click on the Setup directory. Click on the PC_Setup.exe file which executes the KTSync Setup Wizard.

NOTES

- If KTSync Setup Wizard locates an older version of KTSync on your computer, you will be prompted to remove the older program before installing the new version. Select Remove KTSync then click Finish. When removal is complete, click Close. Go to Step 2 to run KTSync Setup Wizard.
- If you have any problems, please refer to the Manual Installation section.

KTSync Setup Wizard

Below are the screen images you will see during the installation of KTSync.

- Click **Next** icon in KTSync Setup Wizard window


KTSync
Welcome to the KTSync Setup Wizard
The installer will guide you through the steps required to install KTSync on your computer.
Click "Next" to continue.
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.
Cancel
Previous
Next

- Click **Next** icon in KTSync Confirm Installation window



- Click **Close** icon in KTSync Installation Complete window and wait for Device Driver Installation Wizard



- **Click Install this driver software anyway** in Windows Security window


Windows Security
Windows can't verify the publisher of this driver software
Don't install this driver software
You should check your manufacturer's website for updated driver software for your device.
Install this driver software anyway
Only install driver software obtained from your manufacturer's website or disc. Unsigned software from other sources may harm your computer or steal information.
See details

- Click **Finish** icon in Device Driver Installation Wizard window


Device Driver Installation Wizard
Completing the Device Driver Installation Wizard
The drivers were successfully installed on this computer.
You can now connect your device to this computer. If your device came with instructions, please read them first.
Driver Name
Status
KoamTac Data Collector...
Ready to use
< Back
Finish
Cancel

Connect KDC to Computer

Using the USB cable included with the KDC, follow the directions below.

- Connect ultra mini USB connector to the KDC.
- Connect Type A USB connector to your PC.
- Wait until your computer beeps and/or displays the message Found *New Hardware.*

Verify COM Port Address

- User can verify installed COM Port in Device Manager



Windows Mobile 5.0+

WARNING: ***PLEASE CONNECT PDA TO PC PRIOR TO INSTALLATION***

1. PC_Setup.exe creates Mobile_Setup.exe file under C:\Program Files\KoamTac\KTSync\Windows.Mobile directory
2. Execute Mobile_Setup.exe

- Select Windows Mobile version to install.



- Click Next icon.


Welcome to KTSync for Windows Mobile Setup
Welcome to the KTSync Utility Software for Windows Mobile Setup program. This program will install KTSync Utility Software for Windows Mobile on your Windows Mobile machine.
WARNING: This program is protected by copyright law and international treaties.
If you wish to exit Setup without installing this software, choose Exit. If you wish to continue installing this software, choose Next.
Exit
Next >>

- Click **OK** icon in Pending Application Install window


Pending Application Install
On the next mobile device connection, the installed applications will be downloaded to the device.
OK

- Connect the PDA and follow the instructions on screen

COM port Assignment

- Connect PDA and follow the instructions on screen
- User should assign a COM port for KDC before using pKTSync.
- User should pair KDC with PDA using PDA *Bluetooth* manager and assign a COM port for *Bluetooth* communication
- Please refer to the PDA manual for the details of COM port assignment method

2.2 Manual Installation

The KDC is equipped with one ultra mini USB port which is used to upload barcode data and to charge the KDC battery. Prior to using the KDC, KTSync software and KDC device driver must be installed on your computer. Using the USB cable included with the KDC, follow the directions below.

NOTE: ***If you have the KDC100, it has two ports, Ultra Mini and standard Type A which swings out. See Figure 2 for more details.***

Windows XP, Vista, and 7

1. Insert the KoamTac Installation CD into your computer's disk drive.
2. Create a directory called KoamTac on your computer.
3. Copy XP.Vista.7 directory from KoamTac CD to KoamTac directory. The XP.Vista.7 directory contains KTSync® programs for Microsoft® Windows XP, Vista, Windows 7 and user manuals.
4. Connect KDC cable to ultra mini USB connector on the KDC.
5. Connect KDC cable to Type A USB connector on your computer. Wait until your computer beeps and/or displays the message *New Hardware Found*. You will be prompted to search for a device driver for KDC.
6. Browse then select *KTReader.inf* file from the KoamTac directory created in Step 2. Follow screen prompts to continue with the device driver installation.

NOTE*: KTReader.inf is the device driver for 32bit Microsoft® Windows XP, Vista, and Windows 7. If you have a 64bit computer, use KTReader.inf file from XP.Vista.64bit folder in the KoamTac directory.*

Windows Mobile 5.0+

Please connect your Windows Mobile PDA to your computer before software installation.

- Create a directory and name it KoamTac on the PDA.
- Copy Mobile5.0_6.0 directory from KoamTac CD to PDA KoamTac directory.
- Mobile5.0_6.0 contains KTSync® programs for Microsoft® Windows Pocket PC 2003, Mobile 5.0, Mobile 6.0 Standard, and Mobile6.0 Professional. It also includes KDC User Manual.

3. OPERATING THE KDC

3.1 Getting Started

Attach Neck Strap to KDC

To prevent possible damage to the KDC, we ***strongly*** recommend wearing it around your neck by the included neck strap. Also, please don't swing KDC by the neck strap because contact with another object may cause it to malfunction or become damaged.

To attach the neck strap:

1. Fit the thin end of neck strap through the pillar of the KDC.
2. Loop the thick end of strap through the thin loop
3. Pull the strap tight to secure

Charge KDC Battery

Prior to using the KDC, you must charge its battery. To charge the battery, follow these directions.

1. Connect the KDC cable to the ultra mini USB connector on the KDC.
2. Connect the KDC cable to Type A USB connector on your computer.
3. Your KDC battery will begin charging. Within a few minutes, two small LEDs on the front panel will illuminate orange. When the battery is fully charged, the LEDs will illuminate green.

KDC100	***KDC200***	***KDC200P***	***KDC300***
2 Hours	*2 Hours*	*2 Hours*	*4 Hours*

Table 2 – Approximate Time to Charge KDC Battery

Configure KDC

The KDC is designed to meet the data collection requirements of many different industries in a variety of dynamic situations. To perform well in these diverse environments, the KDC is designed to be configured easily and quickly. But, to perform at its maximum level, the KDC must be configured properly. Until you are familiar with configuring the KDC, it is recommended that you DO NOT modify the KDC settings. The KDC can be configured in three different methods which are explained in Section 3.3 – KDC Menus, Chapter 4 –Synchronization, and Appendix C – Special Barcodes.

CONFIGURATION METHODS FOR THE KDC

- KDC Menu
- KTSync® Software
- Special Barcodes

Figure 4 - Location of Scroll Buttons

3.2 Basics

Reading Barcodes

Reading a barcode is simple. Point the KDC at a barcode and press the scan button. Be sure to point the scan engine at the barcode, not at your face, and make sure to position the light beam on the barcode. If the barcode is scanned successfully, you will hear one beep and the LEDs will illuminate in green. The scanned barcode data will display along with the scan time and battery level. *Depending on the configuration of your KDC, other information may also display.*



Figure 5 - KDC Display

If the scan was unsuccessful, you will hear two beeps, the LEDs will illuminate in red, and the message ***Failed reading…*** will display. If you have problems scanning a barcode, try the following suggestions while pointing the KDC at the barcode and depressing the scan button.

- Modify the angle of the KDC in relation to the barcode, making the angle bigger or smaller as needed.
- Modify the distance between the barcode and the KDC, moving closer or further away as needed.
- Check option settings defined in the KDC menu section and change options as needed.
- Check that the barcode's width does not exceed the light beam's width and vice versa.

Synchronizing Barcode Data to PC

Use the KTSync® program to synchronize barcode data from the KDC to your PC. Please refer to Chapter 4 for details.

3.3 KDC Menus

Top Menu	Sub Menu / Option	Option / Note
KDC Mode	Normal	Default
	Application	Custom Application
View Data	View/Delete	View/Delete Data
Set Barcodes	**1D**	
	Codabar	Enable/Disable
	Code 11	Enable/Disable
	Code 39	Enable/Disable
	Code93	Enable/Disable
	Code128	Enable/Disable
	EAN8	Enable/Disable
	EAN13	Enable/Disable
	GS1-128	Enable/Disable
	I2of5	Enable/Disable
	Matrix2of5	Enable/Disable
	MSI	Enable/Disable
	Plessey	Enable/Disable
	PosiCode	Enable/Disable
	GS1 DATABAR OMNI	Enable/Disable
	GS1 Limited	Enable/Disable
	GS1 Expanded	Enable/Disable
	S2of5ID	Enable/Disable
	S2of5IA	Enable/Disable
	TLC39	Enable/Disable
	Telepen	Enable/Disable
	Trioptic	Enable/Disable
	UPCA	Enable/Disable
	UPCE0	Enable/Disable
	UPCE1	Enable/Disable
	2D	
	AztecCode	Enable/Disable
	AztecRunes	Enable/Disable
	CodablockF	Enable/Disable
	Code 16K	Enable/Disable
	Code49	Enable/Disable
	DataMatrix	Enable/Disable
	MaxiCode	Enable/Disable
	MicroPDF	Enable/Disable
	PDF417	Enable/Disable
	QRCode	Enable/Disable
	HanXin Code	Enable/Disable
	Postal Codes	
	Postnet	Enable/Disable
	PlanetCode	Enable/Disable
	UKPost	Enable/Disable
	CanadaPost	Enable/Disable
	KixPost	Enable/Disable
	AusPost	Enable/Disable
	JapanPost	Enable/Disable
	ChinaPost	Enable/Disable
	KoreaPost	Enable/Disable
	OCR Fonts	
	OCR OFF	Enable/Disable
	OCR A	Enable/Disable
	OCR B	Enable/Disable
	OCR US Currency	Enable/Disable
	OCR MICRE13B	Enable/Disable
	OCR Semi Font	Enable/Disable

Top Menu	Sub Menu / Option	Option / Note
Code Options	*Codabar*	
	TxStartStop	Enable/Disable
	Check Digit	DoNotVerify/VerifyDoNotTx/VerifyDoTx
	Concatenate	Disabled/Enabled/Required
	Code39	
	Tx StartStop	Enable/Disable
	Check Digit	DoNotVerify/VerifyDoNotTx/VerifyDoTx
	Append	Enable/Disable
	FullASCII	Enable/Disable
	I2of5	
	Check Digit	DoNotVerify/VerifyDoNotTx/VerifyDoTx
	Code11	
	Check Digit	1 digit/2 digits
	Code128	
	Concatenate	Enable/Disable
	Telepen	
	Output	AIM/Original
	UPCA	
	VerifyChkDgt	Enable/Disable
	NumberSys	Enable/Disable
	2DgtAddenda	Enable/Disable
	5DgtAddenda	Enable/Disable
	Req. Addenda	Enable/Disable
	Sep. Addenda	Enable/Disable
	Coupon Code	Enable/Disable
	UPCE	
	Expand	Enable/Disable
	Req. Addenda	Enable/Disable
	Sep. Addena	Enable/Disable
	Check Digit	Enable/Disable
	NumberSys	Enable/Disable
	2DgtAddenda	Enable/Disable
	5DgtAddenda	Enable/Disable
	EAN-13	
	VerifyChkDgt	Enable/Disable
	2DgtAddenda	Enable/Disable
	5DgtAddenda	Enable/Disable
	Req. Addenda	Enable/Disable
	Sep. Addena	Enable/Disable
	ISBN Trans.	Enable/Disable
	EAN-8	
	VerifyChkDgt	Enable/Disable
	2DgtAddenda	Enable/Disable
	5DgtAddenda	Enable/Disable
	Req. Addenda	Enable/Disable
	Sep. Addena	Enable/Disable
	MSI	
	Tx CheckChar	Enable/Disable
	PosiCode	
	A and B	Enable/Disable
	A&B Limited A	Enable/Disable
	A&B Limited B	Enable/Disable
	EAN-UCC	
	UPCEAN VER.	Enable/Disable
	Emulation	RSS Emulate/128 Emulate/No Emulate
	POSTNET	
	Tx CheckDgt	Enable/Disable
	PlanetCode	
	Tx CheckDgt	Enable/Disable

KDC 300 Menu Options – continued

Scan Options	Time Out	0.5 to 10 seconds
	Minimum Length	2 to36 characters
	Partial Display	• Start Position • No. of Char(s)
Data Process	Wedge / Store	• Wedge Only • Wedge & Store • Store Only • Wedge & Store if Sent • Wedge & Store if Not Sent
	Data Format	• Barcode only • Packet data
	Handshake	Enable/Disable
	Terminator	• None • CR • LF • CR+LF • Tab
Data Editor	Prefix	Delete
	Suffix	Delete
	AIM ID	None/Prefix/Suffix
	Partial Data	Start Position/Length
Bluetooth	Power	Enable/Disable
	Pairing	Enter Pairing Mode
	Auto Connect	Enable/Disable
	Auto PowerOff	Enable/Disable
	Auto PowerOn	Enable/Disable
	Beep Warning	Enable/Disable
	PWR OFF Time	1min ~ 30min
	PowerOff Msg	Enabled/Disabled
	MAC Address	12 Characters *Bluetooth* MAC Address
	BT FW Version	1.1.x Bluetooth Firmware Version
	Connect to	Connect to *Bluetooth* device
	Wakeup Nulls	Enabled/Disabled
System	Memory Status	# of Stored Barcode & Amount of Remaining Memory
	Reset Memory	Empty Data Memory
	Sleep Timeout	Disabled to 10 minutes
	Date / Time	YYYY:MM:DD or HH:MM:SS
	Battery	% of Battery Left
	Version	FW Version & Serial Number
	Button Lock	Enabled/Disabled
	Beep Sound	Enabled/Disabled
	Auto Menu Exit	Enabled/Disabled
	Port Status	Enabled/Disabled
	Display Format	• Time & Battery • Type &Time • Type &Battery • Memory Status
	Menu Barcode	Enable/Disable Honeywell Special Barcode
	Scrolling	Enabled/Disabled
	Factory Default	Restore to Factory Default Settings

Table 3 – KDC Menu Options

KDC Mode Menu

The KDC Mode Menu has two options – Normal and Application modes.

- Normal: This is the default mode which provides basic barcode scanning. In Normal mode barcode data can be manipulated directly through the KDC or using KTSync® during the synchronization process.
- Application: This mode allows you to run the user application created by Application Generation Tool described in Chapter 6.

View Data Menu

This menu option allows you to view and/or delete barcodes stored in the KDC.

Set Barcodes Menu

This menu lists all the barcode symbologies supported by your KDC and allows you to select the barcode symbologies you will be scanning. For maximum scan performance, you should select only the symbologies you are scanning. Please refer to Appendix A.1 – Symbologies for a detailed listing of symbologies supported by your KDC.

Code Options Menu

Your KDC supports various Code Options including Transmission of Start and Stop Characters, Symbology Conversion, Verification of Optional Check Character, Transmission of Check Digit, and Concatenate. Please refer to Section 4.3 and Honeywell IT5x80 reference manual for a detailed listing of Code Options for the symbologies supported by the KDC.

Scan Options Menu

- Timeout: Allows you to set the length of time before the KDC will stop scanning a barcode from .5 second up to 10 seconds. The default is 2 seconds.
- Minimum Barcode Length: Allows you to set a barcode length from 2 characters to 36 characters. It is strongly recommended that you maximize the minimum barcode length setting to prevent possible errors. The default is 4 characters.
- Partial Display: Allows you to display partial data. User defines the start position and number of characters to be displayed.

Data Process Menu

Wedge/Store - The KDC provides five modes of data transmission in keyboard wedging mode.

- Wedge Only: Barcode data is NOT stored in memory but transmitted to the host.
- Wedge & Store Only: Barcode data is stored in memory and transmitted to the host.
- Store Only: Barcode data is stored in memory but NOT transmitted to the host.
- Wedge & Store if Sent: If data transmission is successful, barcode data is stored in memory.
- Wedge & Store if Not Sent: If data transmission is NOT successful, barcode data is stored in memory.

Data Format - The KDC provides two data formats, Barcode Only and Packet Data.

- Barcode Only: KDC transmits scanned barcodes only. User may incorporate proper data transmission error detection and correction mechanism in this mode.
  - KDC supports various termination characters for barcode only format.
  - User can select <NONE>, <CR>, <LF>, <CR+LF> or <TAB> as the termination character.
- Packet Data: KDC transmits packet data with checksum to minimize transmission errors.
  - KTSync® sets Data Format to Packet Data format upon execution.
  - User may change Data Format to Barcode only if user prefers to use Barcode only mode but either KTSync program terminates abnormally or user disconnects KDC without exiting KTSync program normally.

Handshake - KDC provides Handshake mode when Data Format is set to Packet Data.

- Handshake Mode will increase the reliability of barcode data transmission.
- The default mode for Handshake is Disabled.
- Data transmission speed is slower when Handshake Mode is Enabled.

Terminator – KDC supports various termination characters when the Data Format mode is set to Barcode Only. This option allows you to select <NONE>, <CR>, <LF>, <CR+LF>, or <TAB> as the termination character. The default terminator is <CR+LF>.

Data Editor Menu

Prefix - Allows you to add a prefix to scanned data which can then be stored in KDC or wedged to the host. The Prefix format must be defined in the data format menu of KTSync. The maximum length for a Prefix is 11 characters. **NOTE:** This Prefix option is different from the Prefix option in KTSync which appends the prefix to data during synchronization.

Suffix - Allows you to add a suffix to scanned data which can then be stored in KDC or wedged to the host. The Suffix must be defined in the data format menu of KTSync. The maximum length for a Suffix is 11 characters. **NOTE:** This Suffix option is different from the Suffix option in KTSync which appends the suffix to data during synchronization.

AIM ID - Allows you to add AIM ID to scanned data which can then be stored in KDC or wedged to the host. AIM ID must be defined in data format menu of KTSync. AIM ID is either added to the end of Prefix or Suffix.

Partial Data: Allows you to display and store partial data. User defines the start position and number of characters to be displayed and stored.

- Select the ***x*** characters from ***y*** position
  - ✓ Set Partial Data Start Position to ***y***, Partial Data Length to ***x,*** Partial Data Action to Select
  - ✓ Partial Data Length ***0*** means Select all characters from ***y*** position.
- Erase the ***x*** characters from ***y*** position
  - ✓ Set Partial Data Start Position to ***y***, Partial Data Length to ***x,*** Partial Data Action to Erase
  - ✓ Partial Data Length ***0*** means Erase all characters from ***y*** position.

Bluetooth Menu - KDC200 / KDC200P / KDC300

The KDC supports *Bluetooth* Ver2.0+EDR. Before utilizing the advantages of Bluetooth functionality with the KDC, you should become familiar with Bluetooth connectivity and its impact on your host environment.

To configure your KDC for Bluetooth functionality, you must use the KDC Menus. To access the menus, simultaneously press the UP and DOWN scroll buttons on the side of the KDC. Use the DOWN button to scroll to Bluetooth then press the Scan button.

Below is a listing of the Bluetooth options and their settings. The default settings for these options have been set to increase the usability of Bluetooth technology without compromising the KDC battery usage. IMPORTANT: We strongly recommend NOT changing these settings until you have fully tested the Bluetooth connection between the KDC and the host device.

For more detailed information regarding Bluetooth functionality with the KDC, please refer to please refer to Chapter 3. For more detailed information regarding Bluetooth functionality with the KDC, please refer to Chapter 4.

- Power - Enabled or Disabled
- Pairing Mode
- Auto Connect - Enabled or Disabled
- Auto Power On - Enabled or Disabled
- Auto Power Off - Enabled or Disabled
- Beep Warning - Enabled or Disabled
- PWR Off Time - 1 to 30 Minutes
- Connect To – Registered *Bluetooth* devices
- PowerOff Msg – Enabled or Disabled
- MAC Address – 12 characters *Bluetooth* MAC Address
- BT FW Version – 1.1.x Bluetooth Firmware Version
- Wakeup Nulls – Enabled or Disabled

System Menu

- Memory Status: Checks the number of stored barcodes and memory usage.
- Reset Memory: Resets KDC memory by erasing all stored barcodes.
- Sleep Timeout: Sets amount of time KDC waits, when not being used, before going to *sleep.*
- Date/Time: Sets the date and time of KDC which can also be set using KTSync®
- Battery: Shows current status of battery power level.
- Version: Shows KDC firmware version and serial number.
- Button Lock: Locks or unlocks KDC scan and scroll buttons.
- Beep Sound: Enables or disables KDC beep sound.
- Auto Exit: Enables KDC to automatically exit KDC Menus.
- Port Status: Enables or disables KDC port messages.
- Display Format: Selection of display format - Time & Battery, Type & Time, Type & Battery, or Memory Status
- Menu Barcode: Enables or disables Honeywell special barcodes
- Scrolling : Enables or disables display scrolling for a barcode with more than 40 characters
- Factory Default: Resets certain KDC options to factory defaults. Factory defaults for the KDC are listed below.

Defaults for KDC300

KDC Mode	**2D Symbologies**	**DATA PROCESS**
Normal	AztecCode	Wedge/Store – Wedge & Store Always
	AztecRunes	Data Format – Barcode Only
1D Symbologies	CodablockF	Handshake- Disabled
	Code16K	Terminator - <CR> + <LF>
Codabar	Code49	
Code 11	DataMatrix	**Data Editor**
Code 39	MaxiCode	AIM ID – None
Code93	MicroPDF	Partial Data – Start 1, Length 0
Code128	PDF417	
EAN8	QR Code	***BLUETOOTH***
EAN13	HanXin Code	Power – Disabled
GS1-128		Auto Connect – Disabled
I2of5	**Postal Codes**	Auto Power On –Disabled
Matrix2of5	Postnet	Auto Power Off- Enabled
MSI	PlanetCode	Beep Warning – Enabled
Plessey	UK Post	Power Off Time – 5 minutes
PosiCode	CanadaPost	PowerOff Msg – Enabled
GS1 DATABAR OMNI	Kix Post	Wakeup Nulls - Enabled
GS1 Limited	Aus Post	
GS1 Expanded	Japan Post	**System**
S2of5ID	China Post	Sleep Timeout – 5 seconds
S2of5IA	Korea Post	Button Lock – Disabled
TLC39		Beep Sound – Enabled
Telepen	**OCR Fonts**	Auto Exit –Enabled
Trioptic	OCR Off	Port Status –Enabled
UPCA		Display Format – Time & Battery
UPCE0	**SCAN OPTIONS**	Scrolling - Enabled
UPCE1	Timeout – 2 seconds	Menu Barcode - Disabled
	Minimum Length – 4 Characters	
	Partial Disp - Start 1, Length 0	

Table 4 – Factory Default Settings for KDC300

3.4 LED Status

LED Color	Status
Green	● Successful Reading ● USB is connected and battery is fully charged
Orange	● Low battery ● USB is connected and battery is charging
Red	● No reading ● Empty battery

Table 5 - Explanation of LEDs

3.5 Empty Battery

The KDC will display the message ***Empty Battery Connect USB*** when the battery is empty. Please charge the KDC IMMEDIATELY to prevent data collecting interruption.

3.6 Buffer Full

The KDC will display the message ***Buffer Full*** when the size of collected data reaches 80KB or the number of collected barcodes is 10,240. To prevent the loss of data, you should synchronize the data then reset the memory when this message displays.

3.7 Reset Feature

The Reset feature lets you restart the KDC if necessary without losing any stored barcode data or option settings. To reset the KDC, follow these steps.

1. Connect the KDC to your PC.
   - KDC100 - Connect to your PC directly using the *swing out,* Type A USB connector. See Figure 7.
   - KDC200 / KDC200P / KDC300 - Connect to your PC using the included cable, attaching the ultra mini USB connector to your KDC and the standard, Type A connector to your PC's USB port. See Figure 6.
2. Press DOWN scroll button and SCAN button simultaneously for 5 seconds.
3. When the LEDs illuminate yellow, release the buttons.
4. The KDC initial screen, **KoamTac Data Collector KDC** displays when reset is complete.

Note:

> *The KDC stores collected data into flash memory and will not lose data or the KDC settings during the reset process.*



Figure 7 - Reset Function of KDC100

Figure 6 - Reset Function for KDC200 - KDC200P - KDC300

3.8 Replace Battery

KDC300 comes with a rechargeable, Lithium-Ion battery. The battery is recharged from any USB port and can be recharged about 300 times before it needs to be replaced.

KoamTac recommends replacing the battery every six months as a declining battery will cause noticeable performance degradation in KDC300. Replacement batteries can be purchased from a KoamTac distributor. Batteries should be disposed properly.

The steps for replacing the battery are as follows.

1. Disassemble the KDC back cover by unscrewing the middle screw.
2. Remove old battery and replace with new battery.
3. Reassemble the back cover.

1		Unscrew the screw which is pointed by the arrow.
2		Remove the battery cover by pulling it down.
3		Remove the battery. Pull out the 2 pin connecter gently.

Figure 8 - Replacing KDC Battery

4. BLUETOOTH - KDC200 / KDC200P / KDC300

The KDC supports SPP (Serial Port Profile) and is tested with the following Bluetooth stacks.

- BlueSoleil
- Broadcom (Widcomm)
- Microsoft Windows XP, Vista, 7, and Mobile5.0+
- Toshiba

4.1 Power

The POWER option allows you to Enable or Disable the Bluetooth functionality of the KDC. To use Bluetooth, this option must be set to Enable. However, like all devices enabled for Bluetooth, the KDC, when set to Enable, will search constantly to connect with a Bluetooth host. Constant searching uses battery power. Unless you are using Bluetooth with your KDC, this option should be set to Disable.

IMPORTANT: To prevent unnecessary power problems, it is strongly recommended that the POWER option be set to Disable if the KDC is idle for an extended period of time.

4.2 Pairing

Before you are able to use Bluetooth, the KDC must be paired with the host device. This paring process only needs to be completed once with each host device. After pairing, the host device will always recognize the KDC as a Bluetooth device unless the Bluetooth configuration is modified. If it is modified, you may need to pair the devices again.

IMPORTANT: The host device must be configured for Bluetooth before it can be paired to the KDC.

To pair the KDC with the host, follow these instructions.

1. Select Pairing from the Bluetooth menu. The message "**Pairing started…"** will displayed.
2. When prompted by the host device, enter the Security PIN "0000".
3. The **"Pairing success"** message will display when the Bluetooth connection is successfully established. The connection must be established before the pairing timeout which is 60 seconds.

- If **"Pairing failed..."** message displays, the Bluetooth connection with the host device failed. If the message "**Connected"** displays, a Bluetooth connection was established.

- It is possible for the message "**Pairing failed..."** to display on the KDC while the host device displays **"Connected"** message. If this occurs, a Bluetooth connection is established.

4.3 Auto Connect

This feature allows the KDC to connect automatically to the host device when the KDC is powered on.

IMPORTANT: Until the host device and KDC have been fully tested, it is strongly recommended that this feature be set to Disable because a host device that does not support this feature can cause problems such as power loss or upload delays.

[Note] KDC tries to connect automatically to the host 10 times during two minutes if *Bluetooth* power is ON, *Bluetooth* is disconnected, Auto Connect is enabled and system Sleep Timeout is set to 5 seconds

4.4 Auto Power On

The Auto Power On option allows the KDC to automatically power on Bluetooth when the SCAN button is depressed. The default setting is Disabled. NOTE: The host may have to open the COM port before reconnecting with the KDC.

4.5 Auto Power Off

The Auto Power Off option works in conjunction with the PWR Off Time option. This option allows the KDC to power off Bluetooth automatically when the KDC is NOT CONNECTED to the host for the time duration specified in the PWR Off Time option.

The default for this option is Enabled. It is strongly recommended to keep it enabled to maximize the operation time of the KDC. If Auto Power Off is enabled, Bluetooth can be manually powered off before specified time in PWR Off Time option.

4.6 Beep Warning

The KDC beeps to acknowledge the status of the Bluetooth connection as follows:

1. One high short beep when Bluetooth is connected.
2. One low short when Bluetooth is disconnected.
3. Five short beeps if:
    - “Beep Warning is ENABLED”
    - “Auto Power Off is DISABLED”
    - “KDC200/200P/300 is DISCONNECTED from HOST”
    - “Bluetooth power is ON”

4.7 PWR OFF Time

The PWR Off Time option works in conjunction with the Auto Power Off option. If Auto Power Off is Enabled, the KDC powers off Bluetooth when the time duration specified in the PWR Off Time option is met and the KDC is NOT CONNECTED to the host. The time settings for this option are from one (1) minute to 30 minutes. The default is five (5) minutes.

4.8 PowerOFF Msg

KDC can display “Bluetooth Disconnected” message if Power Off Message option is Enabled. “Bluetooth Disconnected” message would be displayed if PowerOff Msg option is Enabled and KDC is disconnected with other *Bluetooth* device.

4.9 MAC Address

User can verify KDC Bluetooth MAC Address.

4.10 BT FW Version

User can verify KDC Bluetooth firmware version in BT FW menu.

4.11 Connect To

This option lets you easily connect KDC to Bluetooth devices previously registered in KTSync under the File Menu.

4.12 Wakeup Nulls

The KDC sends three leading Null bytes to wake up connected *Bluetooth* device. This feature can be disabled if connected *Bluetooth* device doesn’t require additional bytes to wake up.

5. SYNCHRONIZATION

When barcode data is collected, it must be uploaded to your application. KTSync®, which is bundled with the KDC, is software that allows barcode data to be uploaded to any PC, PDA, or smartphone running Windows XP, Vista, Windows 7, or Mobile 5.0+. It has three major functions.

- Synchronization - Provides data upload functionality to your applications.
- Keyboard Emulator - Allows scanned data to upload directly into your application as if the data were being entered manually on a keyboard.
- Application Generation - Allows user to create custom applications or download predefined applications such as Master-Slave, Pick/Bin, and DB Lookup.

Additional functions include:

- Prefix and Suffix add-ons to eliminate manual data entry.
- Symbology and Scan Option selections.
- Barcode Wedging options.

5.1 KTSync Menu

KTSync® was installed on your PC during the initial installation process. Before data can be uploaded to any host device, KTSync® must be launched on the host and configured to recognize the KDC. The following screen displays when KTSync® is launched.



Figure 9 - KTSync® Synchronizer Menu

File Menu

- Connect: This option displays the Serial port (COM#) assigned to KDC. You can also use this option to manually assign the Serial port. The Serial port assigned to KDC can be found under Windows Device Manager. The port assignment is used by KTSync® for synchronizing data from the KDC to the host.
- Synchronize: This option manually tells the KDC to synchronize data with the host. While data is being synchronized, KTSync menu options are unavailable. **NOTE: Please do not use your**

computer during data synchronization.

- Bluetooth: This option is not available on KDC100.
- Exit: This option ends the KTSync program. You must re-run KTSync before you can synchronize data on the KDC.



Figure 10 – File Menu

Settings Menu

- Synchronization: Select Synchronize options.
- Barcode & KDC: Select Barcode and KDC options.
- Others: Select Auto Connection and/or Synchronization Confirmation options.



Figure 11 – Setting Menu

Application Menu

- Generation: Create user application or download predefined application.
- Import: Import existing application.
- Import & Download: Import existing application and download into KDC.
- Export: Export created application.



Figure 12 – Application Menu

About Menu - KTSync® - Version Information



Figure 13 – About Menu

5.2 File Menu

Connect to KDC

The KDC connects to a COM port automatically when connected to your PC's USB port. **You can manually assign the KDC COM port using KTSync® Connection submenu under File menu if needed.**

Figure 14 - COM Port Selection for KDC

- The COM port assignment is found in the Windows Device Manager.
- KTSync® will not connect to the KDC if it is in KDC Menus. You must EXIT from the KDC Menus.
- If KTSync® fails to connect automatically to the KDC, please follow these directions.

1. Exit KTSync®.
2. Check that you have connected the KDC to a USB port on your PC.
3. Make sure to use the cable provided with the KDC.
4. Check that the KDC is not in KDC Mode Menu.
5. Restart KTSync®.

NOTE: You can manually assign the COM port using KTSync® Connect option under the File menu.

Synchronize

Under the File Menu, this option allows you to manually synchronize data on KDC with host. This option is similar to clicking on the Synchronize button in the KoamTac Data Synchronizer box.

Bluetooth

This menu option allows you to register up to ten Bluetooth devices including their MAC address, PIN #, and optional prefixes or suffixes. This option enables direct Bluetooth connection between KDC and other Bluetooth devices such as *Bluetooth* printer. User should choose *Bluetooth* device to be connected in "Connect to" menu in *Bluetooth* menu.



Figure 15 - Bluetooth Device Registry

5.3 Synchronization Settings

KTSync® provides several synchronization options for synchronizing data from your KDC to host devices such as your PC, PDA, or smartphone running Windows XP, Vista, Windows 7, or Mobile 5.0+.



Figure 16 - KTSync® Synchronization Settings

Destination of Data

When barcode data is uploaded to the host device, you must assign a destination for the data. Destination of Data options include:

- File - This option means data will be saved in the assigned filename. You can select a different target directory by clicking the New icon. C:\MyData is the default directory. If this directory is not created, you will be prompted to create it before data can be uploaded to a file.

- Active Window - This option means scanned barcode data is sent directly to the active program running on your device as if the data was being entered directly from a keyboard.
- Microsoft Excel - This option means barcode data is being imported directly into Microsoft's Excel. Various parameters can be set when uploading data to Excel.

- Select from Current Running Application – This option allows you to select a currently running application for data synchronization.

Note:

- Data synchronization begins immediately if *Automatically After Connection* is selected. If not selected, data synchronization is started manually by the user.
- Users **SHOULD NOT** operate the PC during the synchronization process. It can interrupt the process causing unreliable results.

Synchronization Methods

Fast Synchronization in Burst Mode

The KDC can synchronize data to a host device in Burst mode or Handshake mode. Burst mode provides the fastest synchronization process but could result error in poor *Bluetooth* environment. Fast synchronization in burst mode is only recommended with USB connection.

Synchronize Normal Data

The KDC will synchronize Normal Data only in KDC memory if Synchronize Normal Data option is selected. If you want all data in KDC memory synchronized, you should select Synchronize Normal Data **and** Synchronize Application Data.

Synchronize Application Data

The KDC will synchronize Application Data only in KDC memory if Synchronize Application Data option is selected. If you want all data in KDC memory synchronized, you should select Synchronize Normal Data **and** Synchronize Application Data.

Clear KDC Memory after Synchronization

The stored barcode data is cleared from the KDC memory after synchronization if this option is selected. The KDC can store a total of 10,240 barcodes or 80KB of barcode data.

- It is important to clear the KDC memory periodically to prevent Buffer Full message which will prevent the KDC from storing additional data.
- Stored barcode data can also be deleted using the Reset Memory feature on the KDC.

Automatically Synchronize after Connection

This option lets you automatically synchronize collected data to your computer immediately when the

KDC is connected to the host.

- IMPORTANT: Remember to configure all options properly before selecting this option.
- Data synchronization can be done manually by clicking the synchronize icon if this option is not selected.

Beep while Synchronization

You can enable or disable the beep tone during the synchronization process. A beep is sounded each and every time barcode data is synchronized if this option is selected. The KDC beeps 5 times when the synchronization process is complete.

Current KDC Wedge Method

The KDC can be configured in one of five Wedge/Store modes -

- Wedge Only - Scanned data is transmitted to the host. The KDC does not store scanned data.
- Wedge & Store - Scanned data is stored in the KDC and transmitted to the host.
- Store Only - Scanned data is stored in the KDC but NOT transmitted to the host.
- Wedge & Store if Sent - Scanned data is stored in the KDC ONLY if transmission to the host is successfully.
- Wedge & Store if Not Sent - Scanned data is stored in the KDC ONLY if transmission to the host is unsuccessfully.

Enable Wedge (Handheld Scanner Mode) - This option will be checked if Wedge Only or Wedge & Store option is selected.

Keep Scan Data in KDC - This option will be checked if Store Only or Wedge & Store option is selected.

Synchronization Options

Synchronize KDC Time with PC Time when Connected

This option enables you to synchronize the KDC date and time with the host date and time. Synchronization of date and time occurs after the data is uploaded to the host device.

Delays

You can set transmission delays between barcodes and characters during the synchronization process. It is important to set proper delays to prevent errors during the transmission of collected barcodes. Some Windows applications such as Excel require longer delay times.

Attachments

Timestamp, Barcode Type, and Serial Number can be attached to the scanned barcode by selecting these options. The Serial Number of the KDC can be attached to the Start or End of Record.

Prefix and Suffix

- Enter the characters you want appended to the front (Prefix) or back (Suffix) of the barcode in the Prefix and Suffix fields.
- The character set is any combination of ASCII characters including alphanumeric, line feed (“\n”), and carriage return (“\r”).

Order and Delimiter

- Select Order of Data – Type, Data, and Timestamp
- Select the Delimiter between Data – Tab, Space, Comma, and Semicolon
- Select the Delimiter between Records – None, LF, CR, Tab, and <LF & CR>

Application Options

Synchronize Non-Compliant Data

The KDC will synchronize both compliant and non-compliant data (filtered data) if Synchronize Non-Compliant Data option is Enabled.

Consolidate Steps in One Record

KTSync will consolidate the data collected in Step 1 with the data collected in Step 2 and/or Step 3. Data will be consolidated into one record instead of individual data records for each step when Consolidate Steps in One Record is Enabled. Non-complete records, i.e. three steps were defined but data was only collected for two steps; would be discarded if this option is Enabled.

Attach Quantity

Quantity would be attached to the left or right of the data if this option is Enabled.

5.4 Barcode & KDC Settings

KTSync® allows you to configure the KDC Scan Options and Barcode Settings. The configurations options for the KDC using KTSync® are similar to the Set Barcodes, Code Options, Data Editing and Scan Options on the KDC Menu. Please refer to Appendix A for proper barcode settings for your application.

NOTE: You must configure barcode and scan options properly for optimal KDC performance.



Figure 17 - Barcode & KDC Settings, Symbologies, Data Editing and Scan Options

Select Symbologies and Symbology Options

The process for scanning and reading barcodes is delicate and complicated. Your KDC, though equipped with a high performance scan engine, if configured incorrectly, may not perform at its peak performance level. To ensure its high performance, the KDC comes configured to optimize its scan engine technology. Unless you clearly understand the impact of your changes to the KDC settings, please do not change factory default settings. Please refer Appendix A for details. Pressing Default icon will reset all symbology related options to factory default settings.

Data Editing Option

Prefix - Allows you to add a prefix to scanned data which can then be stored in KDC or wedged to the host. The Prefix format must be defined in the data format menu of KTSync. The maximum length for a Prefix is 11 characters. **NOTE:** This Prefix option is different from the Prefix option in KTSync which appends the prefix to data during synchronization.

Suffix - Allows you to add a suffix to scanned data which can then be stored in KDC or wedged to the host. The Suffix must be defined in the data format menu of KTSync. The maximum length for a Suffix is 11 characters. **NOTE:** This Suffix option is different from the Suffix option in KTSync which appends the suffix to data during synchronization.

AIM ID - Allows you to add AIM ID to scanned data which can then be stored in KDC or wedged to the host. AIM ID must be defined in data format menu of KTSync. AIM ID is either added to the end of Prefix or Suffix.

Partial Data: Allows you to display and store partial data. User defines the start position and number of characters to be displayed and stored.

- Select the ***x*** characters from ***y*** position
  - ✓ Set Partial Data Start Position to ***y***, Partial Data Length to ***x,*** Partial Data Action to Select
  - ✓ Partial Data Length ***0*** means Select all characters from ***y*** position.
- Erase the ***x*** characters from ***y*** position
  - ✓ Set Partial Data Start Position to ***y***, Partial Data Length to ***x,*** Partial Data Action to Erase
  - ✓ Partial Data Length ***0*** means Erase all characters from ***y*** position.

5.5 Others Settings

Others option under the Settings menu allows you to select four additional settings.

- **Ask Confirmation before Trying Auto Connection** prevents unintentional launch of KTSync.
- **Ask Confirmation before Starting Auto Synchronization** prevents unintentional synchronization of data.
- **Minimize KTSync on Start** will minimize KTSync and send to the tray upon execution.
- **Keep Checking *Bluetooth* Connection** allows reconnection of KDC once *Bluetooth* signal is detected. This feature is useful when moving from *Bluetooth* host device frequently. KTSync will automatically reconnect *Bluetooth* connection when you enter an effective *Bluetooth* network range. *(Not Available on KDC100)*

To select any of these settings, click on the box to the left of the setting. A check mark (√) will display next to the setting to indicate that it is selected.



Figure 18 - KTSync® Confirmation Settings

5.6 Mobile pKTSync

For Mobile Device Use Only

pKTSync provides limited functionality for Pocket PC 2003 and Mobile 5.0+ users.

1. Synchronization - Provides data upload functionality to your applications.
2. Keyboard Emulator - Allows scanned data to upload directly into your application as if the data were being entered manually on a keyboard.

For detailed explanations of these functions, please refer to earlier sections of this chapter.

WARNING: The user must assign the correct COM port to KDC prior to use pKTSync. Please refer to your mobile device manual for details on *Bluetooth* pairing and COM port assignment methods.



Figure 19 – Mobile pKTSync

6. APPLICATION GENERATION

When you select Application menu from the KTSync, you can choose from the following four Applications – Generation, DB Lookup, Master/Slave, and Pick/BIN. User can also download saved programs using Import & Download option.



Figure 20 – Application Menu

When the Application tool is selected, the KDC will beep once to acknowledge a connection between the KDC and the Application tool. KTSync would popup the following warning window if downloaded application in KDC doesn't match with KTSync application tool.



Figure 21 – Application Warning Window

When the Application tool is selected, the KDC will beep once to acknowledge a connection between the KDC and the Application tool. KTSync would popup the following warning window if downloaded application in KDC doesn't match with KTSync application tool.

6.1 Application Generation

KDC Application Generation tool is a robust feature that allows you to create custom applications for collecting and managing barcode data. To create a custom application, select the Generation submenu from the Application menu in KTSync®.



Figure 22 – Application Generation Menu

Generate Application

Generate step 1 - To generate a custom application, click on the Generate Step 1 box which enables you to define the user prompts and data collection settings for Step 1 of your custom application. Below is a description of each field. These prompts are the same when selecting Generate step 2 and Generate step 3. **NOTE: Your custom application can include only Step 1**.

- **First line**

  Enter up to 13 characters which will display on the first line of the KDC

- **Second line**

  Enter up to 13 characters which will display on the second line of the KDC

- **Starting quantity**

  Enter a predefined start quantity for each scanned barcode. The start quantity can be defined from 1 to 128 and is modifiable using up or down side key.

- **Waiting to scan**

  Enter the number of seconds the KDC pauses before the user prompts display. During this timeout period, the user can modify the quantity. If this field is set to zero, the quantity field cannot be adjusted. This field can be defined from "-1" to "30" seconds. "-1" second enables infinite waiting of user quantity input.

- **Enable data filter**

  Click on this box to enable the data filtering option. Data filtering allows you to predefine different aspects of the barcode data you are collecting.

Data Filter Settings

When you select Enable data filtering, you must click on the Settings box to select the Data filter setting. The option for the data filter settings are the same for Step1, Step 2, and Step 3.



Figure 23 – Data Filter Settings

- **Barcode Type**

  This field allows you to select the type of barcodes the KDC will collect. When you click on the box, Select Symbols is enabled. A listing of the symbologies supported by the KDC displays. To select a barcode symbology, click on the box associated with the symbology.

- **Minimum Data Length**

  This field allows you to define the minimum length of the scanned barcode. The length can be between 2 and 36 characters. If a user scans a barcode whose length is less than the defined length, the barcode data is not collected.

- **Maximum Data Length**

  This field allows you to define the maximum length of a scanned barcode. The defined length can be between 2 and 256 characters. If a user scans a barcode whose length is greater than the defined length, the barcode data is not collected.

- **Barcode Collation**

  This option enables you to define a data string that the KDC will use to compare scanned barcodes.
  - Starting Position – This is the start position of the scanned barcode data to be compared with the defined data string.
  - Data String – This is the defined value to be compared with scanned barcode data. This value can be up to 32 characters

- **Collect Partial Data**

  This option allows you to define partial barcode data to be collected when a barcode is scanned. Only the partial data will be stored in the KDC.
  - Start position – This is the starting position that the KDC will use when collecting scanned barcode data.
  - Data Length – This is the length of partial data to be stored by the KDC

- **Check for Duplicated Data**

  This option allows you to prevent collecting duplicated data.
  - Previous Scanned Data – This option allows you to compare the scanned barcode with previously scanned barcode and treat it as non-compliant data if scanned same barcode twice.
  - All Stored Data – This option allows you to compare the scanned barcode with stored barcode data and treat it as non-compliant data if the same barcode already scanned and stored.

- **Don’t Save Non-Compliant Data**

  This field tells the KDC how to manage non-compliant data based on the defined data filtering fields.

If this field is enabled, non-compliant data is NOT stored in the KDC. If this option is not enabled, non-compliant data is stored.

Generate step 2

To include another step in your data collection process, click the box, Generate step 2. This step has the same options as Step 1. In this step, you have the option of repeating step 2 by clicking the box, Repeat Step. NOTE: This field is disabled when your application has three steps.

Generate step 3

To include a third step, click the box, Generate step 3. This step has the same options as step 1 and 2. However, in this step you have the option to repeat steps 2 or 3.

Application Download and Execution

Prior to running your application, it must be downloaded to KDC.

- Click “Download” icon from Application Generation Window.
- Change KDC from Normal mode to Application mode.
  - Press two side buttons simultaneously to enter menu mode
  - Select KDC mode and enter scan button
  - Change to Application mode
  - Save and exit from menu mode
- KDC will run in normal mode if you don’t change to Application mode after downloading the application.

6.2 Predefined Applications

KTSync provides three Predefined Applications – Master/Slave, Pick/Bin, and DB Lookup.

Master/Slave

Master/Slave predefined application allows you to define a ***master*** barcode for comparison with one or more ***slave*** barcodes. The predefined application can be run once or continuously and within either setting, you can define a substring for comparison of master and slave barcodes.

- **Master/Slave Onetime**
  Define one ***master*** barcode and compare it with one ***slave*** barcode.
- **Master/Slave Continuous**
  Define one ***master*** barcode and compare it with multiple ***slave*** barcodes.
- **Collation Options**
  Works in either Onetime or Continuous Mode to compare a substring within the master and slave barcodes.

  - ✓ Master start position - Select the numeric position of start substring character in Pick barcode, 1 to 255
  - ✓ Slave start position - Select the numeric position of start substring character in Pick barcode, 1 to 255
  - ✓ Comparing Barcode Length - Number of characters to be compared, 0 to 255. 0 means all characters.



Figure 24 – Master/Slave Application Settings



Figure 25 – Master/Slave Application Flow Chart

Pick/Bin

The Pick/Bin predefined application is a special version of the Master/Slave predefined application. The Pick/Bin application allows you to define Pick ID and the barcode symbology for comparison with a defined Bin.

- **Number of ID and Symbology**

  Define Pick ID characters from 1 to 32 and the barcode symbology.

- **Pick Start Position and Symbology**

  Select numeric position of start substring character in Pick barcode from 1 to 255 and the barcode symbology.

- **Bin Start Position and Symbology**

  Select the numeric position of start substring character in Bin barcode from 1 to 255 and the barcode symbology.

- **Comparing Barcode Length**

  Select the number of characters to be compared from 0 to 255. 0 means all characters.



Figure 26 – Pick/BIN Application Menu



Figure 27 – Pick/BIN Application Flow Chart

DB Lookup Application

The DB Lookup application allows you to download a database to the KDC which it can then utilize for advanced AUTO-ID applications like displaying additional data after scanning a barcode. For example, using our DB Lookup application, you could download a product database including information like description, price, and stock quantity. With the advanced data functionality built-in to the KDC, you could easily display product price, description, and stock level after the product's barcode is scanned.

Functionality of DB Lookup Application

- The database size cannot exceed 800 records.
- The maximum record size is 128 bytes.
- Each record can have up to 4 fields including the barcode which is the primary key.
- The maximum field size is 39 characters.
- Quantities can be entered by pressing the UP or DOWN scroll buttons after DB fields displayed.
- Quantity can be 1 to 128.
- User can create a database using Microsoft Excel.
    - Excel file must be saved as .txt.
    - Records should be separated by CR/LF
    - Fields should be separated by TAB.
    - Database should end with CR/LF.
    - Last 4 bytes of database should be CR/LF/CR/LF.

DB Lookup Fields and Settings

- **Download DB to KDC -** Downloads user created database to KDC.
- **Starting Quantity -** Enter predefined start quantity for each scanned barcode. The start quantity can be defined from 1 to 128 and is modifiable using up or down scroll buttons.
- **Barcode Field -** Select the position of barcode field in database from 1 to 4.
- **Stored Barcode Start Position -** Select the numeric position of start substring character of barcode in database from 1 to 39.
- **Scanned Barcode Start Position -** Select the numeric position of start substring character of scanned barcode from 1 to 39.
- **Comparing Barcode Length -** Number of characters to be compared from 0 to 255 where 0 is all characters.
- **Display on KDC -** Define database fields to be displayed on KDC. KDC can display one to three fields. KDC will display one field in two or three lines if same field is specified in line entering option.



Figure 28 – DB Lookup Application Menu

7. TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
KDC not working	Dead battery	● Charge battery by connecting KDC to your PC using the included cable
	Hardware failure	● Contact distributor for technical support
KDC not charging	Bad battery	● Replace battery – Contact Local Distributor
	Poor USB port	● USB port doesn't supply proper current to KDC - Charge KDC using a different USB port on your PC
Failed reading	Damaged barcode	● Scan a different barcode
	Out of scan range	● Move the scanner closer to barcode ● Move scanner farther from the barcode
	Incorrect angle	● Change the angle of scanner to barcode
	Symbology not supported	● Contact KoamTac - www.koamtac.com for possibility of custom symbology support
	Scan options	● Check scan option settings
	Dirty scan window	● Clean scan window
	Damaged scan window	● Replace scan window
KDC reads wrong barcode	Dirty scan window	● Clean scan window
	Damaged scan window	● Replace scan window
	Poor quality barcode	● Select only necessary barcodes ● Increase minimum barcode length ● Increase security level
Can't communicate with PC, PDA, or smartphone	USB cable is not connected properly	● Check cable connection between KDC and host device
	Software is not working properly	● Reload the software
	COM configuration	● Check COM port configurations
LED blinks yellow	Low battery power	● Charge the battery by connecting KDC to PC. ● KDC will lose collected data if the battery is empty.
Buffer Full Message	Full Memory	● Clear the Memory using Synchronization program
Empty Battery Message	Empty battery	● Connect USB immediately. ● Synchronize the collected data and charge KDC
Abnormal KTSync Operation on DELL PC	Quickset Utility	● Disable Quickset Utility before using KTSync. ● Dell Quickset utility interrupts normal KTSync operation
	WSED Utility	● Disable WSED Wireless enable/disable utility ● delete the folder C:\Program Files\WSED, which contains a file WSED.exe, with the same icon as in the taskbar ● Delete the registry entry KEY_LOCAL_MACHINE \SOFTWARE\Microsoft\Windows\CurrentVersion\Run\WSED

Table 6 - Troubleshooting Techniques

8. WARRANTY

LIMITED WARRANTY AND DISCLAIMERS

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND BY THE LIABILITY AND WARRANTY CONDITIONS AS DESCRIBED BELOW.

UNDER ALL CIRCUMSTANCES THIS MANUAL SHOULD BE READ ATTENTIVELY, BEFORE INSTALLING AND OR USNG THE PRODUCT.

Serial Number

A serial number appears on the KDC label. This official registration number is strictly related to the device purchased. Make sure that the serial number appearing on your KDC is not removed. Removing the serial number will affect the warranty conditions and liability disadvantageously, so please maintain the label with serial number on the KDC. Units with the serial number label removed should not be operated.

Warranty/Warranty Period/Liability

KoamTac, Inc. (“KoamTac”) manufactures its hardware products in accordance with industry-standard practices. Unless otherwise agreed in a contract, KDC is warranted for a period of one year after purchase, covering defects in material and workmanship except rechargeable battery. KoamTac will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. KoamTac will not be liable in cases (i) in which the unit has been repaired or altered unless done or approved by KoamTac, (ii) in which the unit has not been maintained in accordance with any operating or handling instructions supplied by KoamTac, (iii) in which the unit has been subjected to unusual physical or electrical stress, misuse, abuse, power shortage, negligence or accident or (iv) in which the unit has been used other than in accordance with the product operating and handling instructions. Preventive maintenance is the responsibility of the customer and is not covered under this warranty. Under no circumstance will KoamTac be liable for any direct, indirect, consequential or incidental damages arising out of use or inability to use either the hardware or software, even if KoamTac has been informed about the possibility of such damages.

Warranty Coverage and Procedure

During the warranty period, KoamTac will repair or replace defective products returned to KoamTac warehouse. International customers should contact the local KoamTac office or support center. If warranty service is required, KoamTac will issue a Return Material Authorization Number. Products must be shipped in the original or comparable package, shipping and insurance charges prepaid. KoamTac will ship the repaired or replacement product freight and insurance prepaid. Customer accepts full responsibility for its software and data including the appropriate backup thereof. Repair or replacement of a product during warranty will not extend the original warranty term.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user’s authority to operate the equipment.

9. CONTACT INFORMATION

,

CORPORATE HEADQUARTERS

116 Village Boulevard, Suite 200

Princeton, NJ 08540, USA

PH: 609-734-4335 FAX: 609-228-4373

email: support@koamtac.com

For more information, visit our website - www.koamtac.com

APPENDIX A - BARCODE & SCAN OPTIONS

The process for scanning and reading barcodes is delicate and complicated. Your KDC, though equipped with a high performance scan engine, if configured incorrectly, may not perform at its peak performance level. To ensure its high performance, the KDC comes configured to optimize its scan engine technology. Unless you clearly understand the impact of your changes to the KDC settings, please do not change factory default settings.

KoamTac's KDC products support most major barcode symbologies including 1D, 2D, Postal, and OCR-Fonts. Below is a list of the barcode symbologies supported by the KDC with respect to each models particular area of support. To ensure superior scan performance, remember to select only the required symbologies.

	KDC100	*KDC200*	*KDC200P*	*KDC300*
1D Barcodes	EAN13, EAN8, UPCA, UPCE, Bookland EAN, EAN13 with Addon, EAN8 with Add-on, UPCA with Add-on, UPCE with Add-on, Interleave 2 of 5, ITF14, Code128, Codabar, GS1-128, Code39, Code93, & Code35	EAN13, EAN8, UPCA, UPCE, Bookland EAN EAN13 with Add-on, EAN8 with Add-on, UPCA with Add-on, UPCE with Add-on, Interleave 2 of 5, ITF14, Code128, Codabar, GS1-128, Code39, Code93, & Code35	EAN13, EAN8, UPCA, UPCE, Bookland EAN EAN13 with Add-on, EAN8 with Add-on, UPCA with Add-on, UPCE with Add-on, Interleave 2 of 5, ITF14, Code128, Codabar, GS1-128, Code39, Code93, & Code35	Codabar, Code11, Code32, Code39, Code128, EAN8, EAN13, GS1-128, I2of5, MSI, Plessey, PosiCode, GS1 DATABAR OMNI, GS1 Limited, GS1 Expanded, S2of5IA, S2of5ID, TLC39, Telepen, Trioptic, UPCA, & UPCE
2D Barcodes	*N/A*	*N/A*	PFD417	AztecCode, AztecRunes, CodablockF,Code 16K, Code49, DataMatrix, MaxiCode, MicroPDF, PDF417, & QRCode and HanXin Code
Postal Barcodes	*N/A*	*N/A*	*N/A*	AusPost, CanadaPost, ChinaPost, JapanPost, KoreaPost, KixPost, Planet Code, Postnet (US), & UKPost
OCR Fonts	*N/A*	*N/A*	*N/A*	OCR-A, OCR-B, OCRUSCurrency, OCRMICRE13B, & OCRSEMIFONT

Table 7 - Symbologies Supported by KDC

Equation to Determining Potential Number of Stored Barcodes

The number of barcodes that can be stored in the KDC memory depends on the size of the barcodes.

Example: *If only UPCA barcodes are scanned and the check digit is not transmitted, then each barcode takes up 11 (barcode data) + 2 (added bytes) + 2 (length and type) + 4 (time stamp) = 19 bytes. The maximum number of UPCA barcodes that can be saved is 81,920/19 =4,311.*

If different length barcodes are mixed, then you cannot compute the maximum number of barcodes that can be stored.

Data Buffer Full

When the data buffer is full, the KDC displays a message, **Buffer Full**, ignoring any command to scan barcodes. You must reset the data buffer to continue data collection

APPENDIX B – FAQ

B.1 Symbology

Q: What barcode symbologies are supported by the KDC300?

A: The KDC300 supports most major 1D, 2D barcode symbologies and OCR.

KDC300	***KDC100 / KDC 200 / KDC200P****
2D Barcodes	***1D Barcodes***
AztecCode, AztecRunes, CodablockF, Code16K, Code49, DataMatrix, MaxiCode, MicroPDF, PDF417, QRCode, and HanXin Code	EAN13 EAN8 UPCA UPCE Bookland EAN EAN13 with Add-on EAN8 with Add-on UPCA with Add-on UPCE with Add-on Interleave 2 of 5 ITF14 Code128 Codabar GS1-128 Code39 Code93 Code35
1D Barcodes	
Codabar, Code11, Code32, Code39, Code128, EAN8, EAN13, GS1-128, I2of5, MSI, Plessey, PosiCode, GS1 DATABAR OMNI, GS1 Limited, GS1 Expanded, S2of5IA, S2of5ID, TLC39, Telepen, Trioptic, UPCA, and UPCE	
Postal Barcodes	***2D Barcodes***
AusPost, CanadaPost, ChinaPost, JapanPost, KoreaPost, KixPost, Planet Code, Postnet (US), and UKPost	PFD417 - *KDC200P only*
OCR Fonts	
OCR-A, OCR-B, OCRUSCurrency, OCRMICRE13B, and OCRSEMIFONT	

Table 8 – Listing of Symbologies Supported by KDC

B.2 Host Interface

Q: What interface ports are supported by the KDC300?
A: The KDC300 has one ultra mini USB port which supports USB-Serial. It also supports *Bluetooth* SPP.

Q: What *Bluetooth* protocol stacks are supported by KDC300?
A: The KD300 supports all major *Bluetooth* stacks such as Toshiba®, Widcomm®, BlueSoleil® and Microsoft®. The KDC300 can also connect to other *Bluetooth* stacks supporting SPP (Serial Port Profile).

B.3 Battery

Q: How long will the KDC300 battery last before it needs to be replaced?
A: The battery on the KDC300 can be charged at least 300 times before it needs to be replaced.

Q: How long does it take to charge the KDC300?
A: It takes about 4 hours to fully charge the KDC300 from an empty battery status to a fully charged status.

Q: How many barcodes can a fully charged KDC300 scan?
A: The KDC300 can scan more than 20,000 barcodes with *Bluetooth* connection.

Q: How long will the KDC300 battery lasts in the sleep mode?
A: The KDC300 lasts more than 10 days in sleep mode. If *Bluetooth* is powered ON and connected to a host device, it will last for more than five days.

Q: Can I replace the KDC300 battery?
A: Yes. The KDC300 has a separate compartment for the battery which can be opened easily with a screw driver. Contact your distributor for a replacement battery.

B.4 Memory

Q: How many barcodes can be stored in the KDC300?

A: The KDC300 has 100KB for database memory and 80KB of data memory. User can store 800 records in 100KB database memory and maximum 10,240 barcode data in 80KB data memory.

Q: Can I download stored barcodes or wedge barcodes to my application?

A: Yes. KTSync® is synchronization and wedging software included with the KDC300 which supports host applications running on *Microsoft*® Windows XP, Vista, 7, and Mobile5.0+.

Q: Does the KDC300 support *Blackberry*®, *Symbian*®, *Apple*®, and *Palm*® devices?

A: KTSync® supports devices running Microsoft® Windows XP, Vista, 7, and Mobile5.0+. Applications for *Blackberry*, *Symbian*, *Apple*, *Palm,* and others can be developed using KoamTac's software development kit. Contact KoamTac if you are interested in our SDK.

B.5 Programming

Q: Can the KDC300 be programmed by a KoamTac partner?

A: Yes. KoamTac's Application Generation tool provides an enhanced programming environment for developing custom applications for the KDC.

1. KDC supports, at most, three step data collection processes including the ability to perform various data functionality features.
2. KDC's database lookup function provides enhanced data processes enabling the KDC to display database results with or without scanned barcode data.
3. KDC can display a message from Host enabling two way communications and a messaging application.

Q: Does KoamTac provide customization services for the KDC300?

A: Yes. Custom applications or projects can be developed by KoamTac engineers. This service is provided for an additional fee to KoamTac. For more information regarding this service, please contact KoamTac.

Q: Can a partner develop a PC or PDA application for the KDC300?

A: Yes. A software development kit for devices or applications running *Microsoft*® Windows XP, Vista, Windows 7, and Mobile5.0+ is available to our partners. Partners can use DLL and our demo source code included in the SDK for custom applications.

APPENDIX C - SPECIAL BARCODES

C.1 Set Symbologies

Please refer to Honeywell Adaptus® Technology enabled scanner user manual such as 4600 or 4820.

C.2 Barcode Options

Please refer to Honeywell Adaptus® Technology enabled scanner user manual such as 4600 or 4820.

C.3 Delete Last Scanned Barcode

C.4 Scan Options

Please refer to Honeywell Adaptus® Technology enabled scanner user manual such as 4600 or 4820.

C.5 Scan Timeout

Timeout = 500msec

Timeout = 1sec

Timeout = 2sec

Timeout = 3sec

Timeout = 4sec

Timeout = 5sec

Timeout = 6sec

Timeout = 7sec

Timeout = 8sec

Timeout = 9sec

Timeout = 10sec

C.6 Minimum Barcode Length

Minimum Length = 2

Minimum Length = 3

Minimum Length = 4

Minimum Length = 5

Minimum Length = 6

Minimum Length = 7

Minimum Length = 8

Minimum Length = 9

Minimum Length = 10

Minimum Length = 11

Minimum Length = 12

Minimum Length = 13

Minimum Length = 14

Minimum Length = 15

Minimum Length = 16

Minimum Length = 17

Minimum Length = 18

Minimum Length = 19

Minimum Length = 20

Minimum Length = 21

Minimum Length = 22

Minimum Length = 23

Minimum Length = 24

Minimum Length = 25

Minimum Length = 26

Minimum Length = 27

Minimum Length = 28

Minimum Length = 29

Minimum Length = 30

Minimum Length = 31

Minimum Length = 32

Minimum Length = 33

Minimum Length = 34

Minimum Length = 35

Minimum Length = 36

C.7 Data Process - Wedge/Store

Wedge Only

Wedge & Store

Store Only

Wedge & Store if Sent

Wedge & Store if Not Sent

C.8 Data Process - Data Format - Handshake

Data format - Barcode only

Data format - Packet data

Enable Handshake

Disable Handshake

C.9 Data Process - Termination Character

None

CR

LF

CR+LF

Tab

C.10 Bluetooth

Enable Bluetooth Power

Disable Bluetooth Power

Enter Pairing Mode

Enable Auto Connect

Disable Auto Connect

Enable Auto Power Off

Disable Auto Power Off

Enable Auto Power On

Disable Auto Power On

Enable Beep Warning

Disable Beep Warning

Enable PowerOff Msg

Disable PowerOff Msg

Mac Address

BT FW Version

Enable Wakeup Null

Disable Wakeup Null

C.11 Bluetooth PWR Off Time

1min

2min

3min

4min

5min

6min

7min

8min

9min

10min

11min

12min

13min

14min

15min

16min

17min

18min

19min

20min

21min

22min

23min

24min

25min

26min

27min

28min

29min

30min

C.12 System

Memory Status

Reset Memory

Date/Time

Battery

Version

Button Lock

Button Unlock

Enable Auto Menu Exit

Disable Auto Menu Exit

Enable Port Status

Disable Port Status

Time & Battery

Type & Time

Type & Battery

Memory Status

Enable Scrolling

Disable Scrolling

Factory Default

C.13 Sleep Timeout

Disable

1sec

2sec

3sec

4sec

5sec

10sec

20sec

30sec

1min

2min

5min

10min

C.14 Function

F1

F2

F3

F4

F5

F6

F7

F8

F9

F10

F11

F12

MKDC700B.

MKDC700C.

C.15 Number

0

1

2

3

4

5

6

7

8

9

C.16 Lower Case Alphabet

a

b

c

d

e

f

g

h

i

j

k

MKDC716B.

MKDC716C.

l

m

MKDC716D.

n

MKDC716E.

o

MKDC716F.

p

MKDC7170.

q

MKDC7171.

r

MKDC7172.

s

MKDC7173.

t

MKDC7174.

u

v

w

x

y

z

C.17 Upper Case Alphabet

A

B

C

D

E

F

G

H

I

J

K

┬MKDC714B.

L

┬MKDC714C.

M

┬MKDC714D.

N

┬MKDC714E.

O

┬MKDC714F.

P

┬MKDC7150.

Q

┬MKDC7151.

R

┬MKDC7152.

S

┬MKDC7153.

T

┬MKDC7154.

U

V

W

X

Y

Z

C.18 Control Character

BS

TAB

LF

VT

CR

ESC

Space

DEL

C.19 Symbol Character

!

“

#

$

%

&

‘

(

)

*

+

┬MKDC712B.

,

┬MKDC712C.

-

┬MKDC712D.

.

┬MKDC712E.

/

┬MKDC712F.

:

┬MKDC713A.

;

┬MKDC713B.

<

┬MKDC713C.

=

┬MKDC713D.

>

┬MKDC713E.

?

┬MKDC713F.

@

┬MKDC7140.

[

┬MKDC715B.

\

┬MKDC715C.

]

┬MKDC715D.

^

┬MKDC715E.

_

┬MKDC715F.

`

┬MKDC7160.

{

┬MKDC717B.

|

┬MKDC717C.

}

~

Start-String

Stop-String

Note:

- *You can compose a string up to 16 characters.*
- *A string would be composed by scanning the "Start-String", number/alphabet/special characters, and "Stop-String" special barcodes.*
- *The KDC will abort string composition if you do not scan "Stop-String" in one minute after scanning "Start-String" and number/alphabet/special characters.*

INDEX

1D 26, 31
2D 26, 31
Auto..... 27, 79
barcode scanner *8*
Battery..... *23*, 27, *31*, *84*, *85*
Beep..... 27, 31, 45, 80
Bluetooth 27, 79
Button..... 27, 31
Clear 44, 61
Connect..... 27, 79
Data 27
data collectorSee barcode scanner
Date 27, 31
Delay..... 46
Delete..... 26
Delimiter..... 46
GS1-128..... 64, 66
EAN13..... 64, 66
EAN8..... 64, 66
Factory..... 27
Factory Default..... 31, *85*
File.....38, 41, 43
Format 27, 29
Full 32, 61
Handshake 27, 29
ITF14 .....64, 66
KDC 26, 27
KDC300 31
KoamTac*8*, *33*, *61*, *62*, *66*, *67*, *68*
KTSync®*25*, *29*, *31*, *38*, *40*, *41*, *43*, *47*, *67*
LED.....25, 32, 33, 61
Memory.....27, 31, 61, 67
Menu.27, 28, 29, 38, 39, 40, 41
Minimum 28
Option 27, 28, 38, 46, 64
Order 46
Pairing 27, 79
PDA 43, 61, 68
Power 27, 79
Prefix 38, 46
Process 27, 29
Reset..... 27, 31
Scan 27, 28, 38, 45, 47, 61, 64
Serial..... 27, 62
Sleep..... 27, 31
Special Barcodes *24*
Status..... 27, 31, 32
Store 27, 29, 30, 45
Suffix..... 46
Symbology 38, 66
Synchronization*25*, *38*, *39*, *43*, *44*, *45*, *46*, *49*, *61*
Terminator..... 27, 29
Time 27, 28, 31, 46
UPCA 64, 65, 66
UPCE 64, 66
USB..... 32, 33, 41, 61
Version..... 27, 31
View 28
Website .....See Koamtac
Wedge..... 27, 29, 45